



OPTIONAL MINI ACCESSORY GUIDE



360-770-5523
sales@boatliftsintl.com
www.boatliftsintl.com

Single Pole Guides

These vertical guides help to direct your pwc over boat lift.

They also provide a constant reference point for placement of the pwc over the lift, even in waters of fluctuating levels.



Bow Stop

This positioning guide will allow you to stop at the perfect point each time. Just idle forward until your pwc touches the stop and press the up button on the remote.

If you have a tennis ball hanging from your garage for your car, this stop is for you.



Side Deck and Brackets

This side deck allows you to access your pwc when positioned perpendicular to the dock.

